



## **MULTI-CHANNEL HEADSET SYSTEM**

Throughout HRX, you will have the ability to select from the many different experiences happening within the Ballroom. We will be providing you with a headset that will allow you to change the sound source as you move throughout the room. Headsets will be picked up and returned at the same location each day. To ensure the best experience possible, please read the instructions in this document explaining how to change channels on the headset.

We will have staff available at the headset station to support you should you run into any technical difficulties. There will also be signage throughout the room with the associated color for each stage/station.

Headsets will require a charge at the end of each day. It is important you return the headsets before you exit the venue. Our team will sanitize the headsets and you will be able to pick up a new headset at the beginning of each day.

**BE SURE TO RETURN ALL HEADSETS AT THE END OF THE DAY TO THE LOCATION THEY WERE RECEIVED. HEADSETS WILL NEED TO BE CHARGED AND SANITIZED!**



### Headphone Changing Channels

1. Turn on: Press and hold power button (1 second)
2. Change channel: Press power button quickly (do not hold)
3. Turn off: Press and hold for (2 seconds)

### Stations & Colors

Main Stage: **Red**

Stage 2: **Yellow**

Innovation Stage: **Green**

Roundtable 1: **Purple**

Roundtable 2: **Blue**

HRStv: **Turquoise**